

Inset door handles.







Strong MFC cladding.



Non-marking feet.





Well placed vents to the rear and base.







IEC power cable into the mains.



Isolated power compartment for electrical safety.

